

AMETEK Part Number	Customer Part Number	Description	Aircraft Variant
182972	10-60735-2	OXYGEN PRESSURE INDICATOR	-400, -8
260461	60B00120-1	OXYGEN PRESSURE INDICATOR	-400, -8
260516	60B00120-2	DUAL OXYGEN PRESSURE INDICATOR	-400, -8
260519	60B92012-1	FUEL TEMPERATURE INDICATOR	-400, -8
520467	60B00108-7	COMP DUCT TEMPERATURE INDICATOR	-100, -200, -300
520487	60B00126-4	APU TACHOMETER INDICATOR	-100, -200, -300
521314	60B00117-5	CSD OIL TEMPERATURE INDICATOR	-100, -200, -300
521956	60B40136-2	ENGINE BREATHER TEMP INDICATOR W/AIDS	-100, -200, -300
522403	60B00130-203	ENGINE OIL TEMPERATURE INDICATOR	-100, -200, -300
10100N01Y00	S271U121-6	HYDRAULIC QUANTITY INDICATOR	-400, -8
10100N02Y00	S271U121-6	HYDRAULIC QUANTITY INDICATOR	-400, -8
10100N03Y00	S271U121-6	HYDRAULIC QUANTITY INDICATOR	-400, -8
10121B01Y01	S271U121-8	HYDRAULIC QTY INTERFACE MODULE	-400, -8
10121B02Y02	S271U121-8	HYDRAULIC QTY INTERFACE MODULE	-400, -8
10284N01N00	S231T282-4	RUDDER TRIM INDICATOR	-400, -8
8DJ173LWH1	60B00145-3	OIL QUANTITY INDICATOR	-100, -200, -300
8DJ175LXS2	60B00133-103	EXHAUST GAS TEMPERATURE INDICATOR	-100, -200, -300
8DJ176WBA2	60B00132-103	N2 % RPM INDICATOR	-100, -200, -300
8DJ176WBD2	60B00144-2	N1 INDICATOR	-100, -200, -300
C-5C	C-5C	MAGNETIC STANDBY COMPASS	-100, -200, -300, -400, -8
C-5H	C-5H	MAGNETIC STANDBY COMPASS	-100, -200, -300, -400, -8
C-5M	C-5M	MAGNETIC STANDBY COMPASS	-400, -8
HSL-OC12E	S231T282-3	RUDDER TRIM INDICATOR	-100, -200, -300
SEDL-OC4AH	60B00131-20	OIL PRESSURE INDICATOR	-100, -200, -300
SEDL-OC4G	60B00131-15	DUAL OIL PRESSURE INDICATOR	-100, -200, -300
SEDL-OC4N	60B00131-202	DUAL OIL PRESSURE INDICATOR	-100, -200, -300
SEDL-OC4P	60B00131-204	DUAL OIL PRESSURE INDICATOR	-100, -200, -300
SEDL-OC4R	60B00131-205	DUAL OIL PRESSURE INDICATOR	-100, -200, -300
SEDL-OC4S	60B00131-206	DUAL OIL PRESSURE INDICATOR	-100, -200, -300
SEL-OC3J	60B00129-14	FUEL PRESSURE INDICATOR	-100, -200, -300
SEL-OC4G	60B00131-16	OIL PRESSURE INDICATOR	-100, -200, -300
SEL-OC4H	60B00131-14	OIL PRESSURE INDICATOR	-100, -200, -300
SEL-OC4J	60B00131-17	ENGINE OIL PRESSURE INDICATOR	-100, -200, -300
SEL-OC4K	60B00131-103	OIL PRESSURE INDICATOR	-100, -200, -300
ST-106AB	6685-00-951-8492	PRESSURE TRANSMITTER	-100, -200, -300
VIL-OC4K	60B00131-101	OIL PRESSURE INDICATOR	-100, -200, -300
VT-O306D-2	VT-O306D-2	OIL/FUEL PRESSURE TRANSMITTER	-100, -200, -300