

AMETEK Part Number	Customer Part Number	Description
182972	10-60735-2	OXYGEN PRESSURE INDICATOR
260461	60B00120-1	OXYGEN PRESSURE INDICATOR
260516	60B00120-2	DUAL OXYGEN PRESSURE INDICATOR
260519	60B92012-1	FUEL TEMPERATURE INDICATOR
520467	60B00108-7	COMP DUCT TEMPERATURE INDICATOR
520487	60B00126-4	APU TACHOMETER INDICATOR
521314	60B00117-5	CSD OIL TEMPERATURE INDICATOR
521956	60B40136-2	ENGINE BREATHER TEMP INDICATOR W/AIDS
522403	60B00130-203	ENGINE OIL TEMPERATURE INDICATOR
10100N01Y00	S271U121-6	HYDRAULIC QUANTITY INDICATOR
10100N02Y00	S271U121-6	HYDRAULIC QUANTITY INDICATOR
10100N03Y00	S271U121-6	HYDRAULIC QUANTITY INDICATOR
10121B01Y01	S271U121-8	HYDRAULIC QTY INTERFACE MODULE
10121B02Y02	S271U121-8	HYDRAULIC QTY INTERFACE MODULE
10284N01N00	S231T282-4	RUDDER TRIM INDICATOR
8DJ173LWH1	60B00145-3	OIL QUANTITY INDICATOR
8DJ175LXS2	60B00133-103	EXHAUST GAS TEMPERATURE INDICATOR
8DJ176WBA2	60B00132-103	N2 % RPM INDICATOR
8DJ176WBD2	60B00144-2	N1 INDICATOR
C-5C	C-5C	MAGNETIC STANDBY COMPASS
C-5H	C-5H	MAGNETIC STANDBY COMPASS
C-5M	C-5M	MAGNETIC STANDBY COMPASS
HSL-OC12E	S231T282-3	RUDDER TRIM INDICATOR
SEDL-OC4AH	60B00131-20	OIL PRESSURE INDICATOR
SEDL-OC4G	60B00131-15	DUAL OIL PRESSURE INDICATOR
SEDL-OC4N	60B00131-202	DUAL OIL PRESSURE INDICATOR
SEDL-OC4P	60B00131-204	DUAL OIL PRESSURE INDICATOR
SEDL-OC4R	60B00131-205	DUAL OIL PRESSURE INDICATOR
SEDL-OC4S	60B00131-206	DUAL OIL PRESSURE INDICATOR
SEL-OC3J	60B00129-14	FUEL PRESSURE INDICATOR
SEL-OC4G	60B00131-16	OIL PRESSURE INDICATOR
SEL-OC4H	60B00131-14	OIL PRESSURE INDICATOR
SEL-OC4J	60B00131-17	ENGINE OIL PRESSURE INDICATOR
SEL-OC4K	60B00131-103	OIL PRESSURE INDICATOR
ST-106AB	6685-00-951-8492	PRESSURE TRANSMITTER
VIL-OC4K	60B00131-101	OIL PRESSURE INDICATOR
VT-O306D-2	VT-O306D-2	OIL/FUEL PRESSURE TRANSMITTER

**Aircraft Variant**

-400, -8

-400, -8

-400, -8

-400, -8

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-400, -8

-400, -8

-400, -8

-400, -8

-400, -8

-400, -8

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300, -400, -8

-100, -200, -300, -400, -8

-400, -8

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300

-100, -200, -300