

AMETEK Part Number	Customer Part Number	Description
522396	9302393-001	HYDRAULIC OIL QUANTITY INDICATOR
522406	9302328-001	DC VOLT / AMMETER
522781	9302757-003	TOTAL FUEL USED INDICATOR
522783	9302350-002	CABIN PRESSURE INDICATOR
522792	9302473-002	PROPELLER SPEED INDICATOR
522794	9302478-002	ENGINE OIL TEMP / PRESS INDICATOR
522795	9302481-002	OIL TEMP / PRESS INDICATOR
522797	9302391-002	HYDRAULIC BRAKE INDICATOR
522809	9302475-001	BATTERY / FUEL TEMP INDICATOR
522814	9302757-004	TOTAL FUEL USED INDICATOR
522834	9302757-004	TRIM POSITION INDICATOR
522858	9302471-003	DUAL FLAP POSITION INDICATOR
522942	8SC0065	FLAP DEGREES INDICATOR
522948	9302472-005	ENGINE TORQUE INDICATOR
523048	523048	GAS GENERATOR SPEED INDICATOR
523250	9302392-003	DUAL HYDRAULIC PRESSURE INDICATOR
523267	9302337-002	CABIN TEMPERATURE INDICATOR
523347	9302476-004	ITT INDICATOR
523401	9302472-006	ENGINE TORQUE INDICATOR
523402	9302476-010	ITT INDICATOR
523535	9302481-003	PROP OIL PRESSURE / TEMP INDICATOR
10223N01R00	S9303265-001	NP INDICATOR
10224N01R00	S9303264-001	NG % RPM INDICATOR
10225N01W00	S9303262-003	% TORQUE INDICATOR
10227N01T00	S9303262-002	ITT INDICATOR
10251N01T00	S9303262-001	ITT INDICATOR